

## Group Members:

1. Jawad Ahmed (20P-0165)
2. Farhan Abbasi (20P-0044)


**LAB TASK 05: Sharing Files between two computers Via LAN Cable.**

In this task we are going to share the files between two computers using the LAN cable. The procedure for this really simple.


**Step1: Connect Both PC's with LAN Cable**

**Step2: Enable Network Sharing on Both PCs**


**Go to Control Panel -> Then select Network and Internet operation from their.**




**Then select Network and Sharing Center.**




Then select **Ethernet** the pop up window will open.




Then select on properties. New window will open Check the '**Internet Protocol Version 4 (TCP/IPv4)**' option the list.



After doing all these steps then select the option '**Advance Sharing setting**'. In that check the following option so that you are able to transfer files between two computers.





We are assuming that your friend is also doing same steps on his PC.

Now Assign IP addresses to both PC's.

Here, you need to configure the two PCs with different IP settings.

On computer 1, select the option "Use the following IP address." and, put the following

**values: IP Address: 192.168.10.10**

**Subnet mask: 225.225.225.0**

**Default gateway: empty**

You can use any Class A or B IPaddress. In case you are not sure what this all means, better stick with this example.

On the second computer, do similar steps, but flip the IP address and Default gateway

**values: IP address: 192.168.10.5**


**Subnet mask: 225.225.225.0**

**Default gateway: empty**

**Final Step:**

**Now all the steps are done. Open the My Computer -> Network.**

**You will see your friend PC their. Now you are able to transfer files from your computer to your friend computer. We are showing a demo that how would you transfer the files.**




The folder you are sharing you have to give access of that folder to everyone so that you are able to share that folder.

Giving the access is really simple follow these two pictures to give access.


Once that done now go to your friend PC you will be able to see the folder that you shared. I have shared the folder name **Dataset**.

**Here is the confirmation screen shots.**



## Choose people to share with


Type a name and then click Add, or click the arrow to find someone.

Name	Permission Level
 pratik	Owner

[I'm having trouble sharing](#)

Share

Cancel




## Second Computer Configuration Screenshots:



Adjust your computer's settings

View by: Category



### Ethernet Status


General

Connection

IPv4 Connectivity:	No Internet access
IPv6 Connectivity:	No network access
Media State:	Enabled
Duration:	00:10:36
Speed:	1.0 Gbps

Details...

Activity

	Sent	Received
		
Bytes:	48,128	70,406

Properties Disable Diagnose

Close

## Ethernet Properties










Networking **Sharing**

Connect using:

 Realtek PCIe GBE Family Controller

Configure...

This connection uses the following items:

- ☒  QoS Packet Scheduler
- ☒  Internet Protocol Version 4 (TCP/IPv4)
- ☐  Microsoft Network Adapter Multiplexor Protocol
- ☒  Microsoft LLDP Protocol Driver
- ☒  Internet Protocol Version 6 (TCP/IPv6)
- ☒  Link-Layer Topology Discovery Responder
- ☒  Link-Layer Topology Discovery Mapper I/O Driver

Install...

Uninstall

Properties

Description

Allows your computer to access resources on a Microsoft network.

## Internet Protocol Version 4 (TCP/IPv4) Properties

### General

You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.

☐ Obtain an IP address automatically

☒ Use the following IP address:

IP address:

192 . 168 . 1 . 1

Subnet mask:

255 . 255 . 255 . 0

Default gateway:

192 . 168 . 1 . 2

☐ Obtain DNS server address automatically

☒ Use the following DNS server addresses:

Preferred DNS server:

8 . 8 . 8 . 8

Alternate DNS server:

.

☐ Validate settings upon exit

Advanced sharing settings

Control Panel > Network and Internet > Network and Sharing Center > Advanced sharing settings

#### Change sharing options for different network profiles

Windows creates a separate network profile for each network you use. You can choose specific options for each profile:

Private ☐

Guest or Public (current profile) ☒

All Networks ☐

##### Public folder sharing

When Public folder sharing is on, people on the network, including homegroup members, can access files in the Public folders.

- ☒ Turn on sharing so anyone with network access can read and write files in the Public folders  
☐ Turn off Public folder sharing (people logged on to this computer can still access these folders)

##### Media streaming

When media streaming is on, people and devices on the network can access pictures, music, and videos on this computer. This computer can also find media on the network.

[Choose media streaming options...](#)

##### File sharing connections

Windows uses 128-bit encryption to help protect file sharing connections. Some devices don't support 128-bit encryption and must use 40- or 56-bit encryption.

- ☒ Use 128-bit encryption to help protect file sharing connections (recommended)  
☐ Enable file sharing for devices that use 40- or 56-bit encryption

##### Password protected sharing

When password protected sharing is on, only people who have a user account and password on this computer can access shared files, printers attached to this computer, and the Public folders. To give other people access, you must turn off password protected sharing.

- ☐ Turn on password protected sharing  
☒ Turn off password protected sharing

Save changes Cancel

Type here to search



20°C Haze 10:47 am 09/12/2012

