Name : Jawad Ahmed


Roll No : 20P-0165

Section : BCS-5A

HOME WORK NO 4

Task1: DNS server configuration in Packet Tracer.

DNS Server Configuration



```
C:\>ping pc1

Pinging 192.168.1.4 with 32 bytes of data:


Reply from 192.168.1.4: bytes=32 time<1ms TTL=128

Ping statistics for 192.168.1.4:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 0ms, Maximum = 0ms, Average = 0ms


C:\>
```

In this task we have to create connection between pc's using the DNS server so the PC's can ping each other using pc's name.

1: First of all the **ON** the DNS service. Click on the **services** and then select DNS.



2: Provide the IP's of the PC's to which you want to ping.



Once that provided then go the command prompt of PC0 and issue the command => ping pc1


You will see pc0 will start pinging pc1. Pc1 is the name of the PC now it is the task of the DNS server to translate the name of the PC to corresponding IP address.

```
C:\>ping pc1
Pinging 192.168.1.4 with 32 bytes of data:
Reply from 192.168.1.4: bytes=32 time<1ms TTL=128
Ping statistics for 192.168.1.4:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 0ms, Maximum = 0ms, Average = 0ms
C:\>
```

Task2: Configuring DHCP server on a Router.

The DHCP is used to assign IP's randomly. We can make mistakes while assigning IP's so we are using the DHCP that will assign IP for our PC's and also the default gateway and DNS Ip also assigned. I will be using the router CLI to activate the DHCP and provide the network for the IP's.

First of all create this topology and then we will do configuration for all the DHCP.



Once that done go to the router CLI and then issue these commands to configure router.

1: Enter no first.

```
Would you like to enter the initial configuration dialog? [yes/no]: no


Press RETURN to get started!

Router>
```

2: Then issue these commands in the cli and all the configuration of DHCP is done.

```
Router>enable
Router#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#interface
Router(config)#interface
Router(config)#interface Gig
Router(config)#interface GigabitEthernet
Router(config)#interface GigabitEthernet
Router(config)#interface GigabitEthernet
Router(config)#interface GigabitEthernet 0
Router(config)#interface GigabitEthernet 0
Router(config)#interface GigabitEthernet 0/
Router(config)#interface GigabitEthernet 0/0/0
%Invalid interface type and number
Router(config)#interface GigabitEthernet 0/0
Router(config-if)#ip address 192.168.1.1 255.255.255.0
Router(config-if)#no shutdown
Router(config-if)#
%LINK-5-CHANGED: Interface GigabitEthernet0/0, changed state to up
%LINEPROTO-5-UPDOWN: Line protocol on Interface GigabitEthernet0/0, changed state to up
```

3: Once that done go the PC0 and in the IP configuration instead of static select DHCP. It take some time to assign IP's.




The IP is assigned using the DHCP. You can ping two PC'S using IP's to verify this.


Task3: Configuring DHCP service on a generic server

1: First of all build I have built this Topology.

Configuring DHCP service on a generic service.




2: Once that create then click on the DNS_Server and assign IP's, subnet mask and the DNS_Ip to it.




Once that configuration done then next step go the services tab and click on the DHCP service. The serverPool is by default created provide the default gateway and subnet mask and start IP address. We sometime reserved some IP addresses in this case I have reserved first 10 Ip addresses and the Max users will change from 255 to 245. After the click on the save and pool is created successfully.



After pool is created go to any PC and in the IP configuration click on the dhcp instead of static IP configuration and IP will be assigned to the PC by DHCP.




The Ip assigned successfully by using the DNS server. Pinging PC10 to Laptop0 the IP assigned by DHCP.





Task4:: Configuring DHCP, DNS and Web Server configuration in cisco packet tracer.

Step1: Create This Topology.



Step2: Assign Ip address to F0/0 and F0/1 of router.






Step3: Open the CLI tab in the **Router0** and go the configuration mode and execute the following commands.

To Go To the configuration mode => **configure terminal**

Router#
Router#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#ip dhcp pool P1
Router(dhcp-config)#network 192.168.1.0 255.255.255.0
Router(dhcp-config)#default-router 192.168.1.2
Router(dhcp-config)#ip dhcp pool P2
Router(dhcp-config)#network 192.168.2.0 255.255.255.0
Router(dhcp-config)#default-router 192.168.2.2
Router(dhcp-config)#


Step4: Apply follows setting on DHCP IP configurations.



Step5: Open the services tab and enable DHCP Services and Add Pool P1 and Pool P2 with respective Ip Address.



Step 6: Apply follows setting on DNS Ip configuration.




Step7: Enable DNS Services of DNS and add two resources records. Remember To On the DNS Service.

PacketTracer*

PacketTracer


*




Step8: Apply following IP configuration on the Web Server.

Configuration		x
Configuration		٨
Comparation		
OHCP	Static	
IPv4 Address	192.168.1.7	
Subnet Mask	255.255.255.0	
Default Gateway	192.168.1.2	
DNS Server	192.168.1.9	
v6 Configuration		
Automatic	Static	
IPv6 Address		1
Link Local Address	FE80::260:2FFF:FE92:3554	
Default Gateway		
DNS Server		
02.1X		
Use 802.1X Security		
Authentication	MD5	~
Username		
Password		

Step9: Go to Services Tab and then Enable Http and Https in Web Server.




Step10: Edit the index.html file



Step11: Now go to every PC and on their IP configuration tabs, enable DHCP. Every PC should be able to obtain an IP address, default gateway and DNS server.

Click PC17->Desktop->IP configuration. Then enable DHCP:



Do it for all the PC's.

Now let's Open the PC17 browser and open the URL that you have added. The index file will be shown to you

have added. The index file will be shown to you. PC17 Physical Config Desktop Programming Attributes Web Browser Х URL http://www.webserver.com Stop Cisco Packet Tracer Jawad Ahmed (20P-0165) BCS-5A Quick Links: A small page **Copyrights** Image page <u>Image</u> Top

How it works?

We have **DNS-1** in which we save domain name and told that when this domain name typed go to that IP server and pick index file from that server and how to user.

For Example: When user type <u>www.webserver.com</u> then the webserver (192.168.1.7) index file is shown and work same for all the other PC's.

Test the configuration by pinging PC2 from PC1. Ping should succeed.